

HANECO LIGHTING LED INSTALLATION GUIDE

PURO400 SERIES

- 1) Ensure mains power has been isolated/turned off.
- 2) Remove diffuser from base by rotating it in an anti-clock wise direction.
- 3) Position base plate with cables feeding through the central protection grommet.
- 4) Fix to ceiling or appropriate surface with screws provided or other appropriate method.
- 5) Install/connect cables into terminal block.
- 6) Select required colour temperature using the three position switches 3000K, 4200K, 5700K on the LED board.
- 7) Replace diffuser ensuring the three locating pins on the baseplate align with the diffuser and tighten in a clock wise direction.
- 8) Restore power and test light for illuminates.

EMC: EN 55015, EN 61547, EN 61000-3-2, EN 61000-3-3

Installation

1 TURN OFF POWER at the source.

2 Mark ceiling (Screw and cable locations), then drill 3 holes.

3 Install 3 drywall anchors.

4 Run power cord through the central hole of base and screw base to ceiling. Do not touch LED Chips while performing this step.

5 Connect power cord to terminals as shown in the diagram.

6 Adjust hold-time, detection area, and daylight sensor by turning the knobs.

7 Switch to the appropriate colour temperature.

8 Reattach cover.

9 Restore power.

5 With emergency kit

- Intelligent automatic recharging function.
- 3 hours emergency operation.
- LED charge status display.

6 With sensor

- Hold-time adjustable from 5 seconds to 30 minutes.
- Day light sensor with adjustable threshold from 5 to 2000 lux.
- Wide detection area, max. 10m.

Without emergency kit
UA: Unswitched Live
SA: Switched Live
With emergency kit

DL: Day Light
CW: Cool White
WW: Warm White

With sensor

* The Installation must be carried out by an electrician

PRODUCT CODE: - CL25W400R-MULTI - CL25W400R-MULTI-EM-S
- CL25W400R-MULTI-EM - CL25W400R-MULTI-MS