HANECO COMMERCIAL LED DOWNLIGHT INSTALLATION GUIDE

ASTRAL

Product Code: AST10W-115 AST15W-145 AST20W-170 AST25W-190 AST30W-235

This range of Haneco Lighting LED product(s) have been tested as AS/NZS60598.2.2:2001 standards and are approved to the luminaire will not exceed 90°C when side abut or covered with ceiling insulation.

Building insulation is used to abut and cover the luminaire must meet the following requirement:


- 1. Be of a type that can maintain it's dimensions and structural integrity when exposed to the maximum surface temperatures of the class of luminaire, being 90°C and must withstand a 30s needle flame test carried out in accordance with AS/NZS 60695.11.5 with the flame applied to all surfaces of the sample.
- 2. (New Zealand only) Loose fill insulation as defined in NZS4246 is not permitted to abut or cover this luminaire.

Safety Instructions:

To ensure correct function and safety, please read and follow all instructions carefully before using the product.

- 1. Turn off power supply before installation or before doing any maintenance work.
- 2. Do not install any luminaire near the heat source.
- 3. Do not exceed the nominal supply voltage or amperage ratings.
- 4. All wiring and installation of the light fitting must adhere to local and national wiring rules.
- 5. Take care not to pull any electrical wires during unpacking as this may damage the connection.
- 6. Lay out all the components on a smooth surface and make sure there are no components missing before assembling.
- 7. To avoid injury or damage to the fitting, please ensure that power leads and screws are secure before connecting the power.
- 8. Please keep instructions for future reference.
- 9. Please refer to IP (Ingress Protection) rating of this luminaire when deciding the location of installation.

Installation Instructions:



Ceiling cutout table:

Product Code	AST10W-115	AST15W-145	AST20W-170	AST25W-190	AST30W-235
Ceiling Cutout (mm)	90	120	140	160	200

Warning:

- a. Type Y: If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or by a service agent or licenced electrician in order to avoid hazard.
- b. Non-user replacable light source.
- c. The lens cover of the luminaire is secured by glue, unremovable.
- *Please ensure that the Driver is not covered by insulation or other building materials.





