
Surface Mount Kit

Safety Instructions

To ensure correct function and safety, please read and follow all instructions carefully before using the product.

- 1. Turn off power supply before installation or before doing any maintenance work.
- 2. Do not install any luminaire near the heat source.
- 3. Do not exceed the nominal supply voltage or amperage ratings.
- 4. All wiring and installation of the light fitting must adhere to local and national wiring rules.
- 5. Take care not to pull any electrical wires during unpacking as this may damage the connection.
- 6. Lay out all the components on a smooth surface and make sure there are no components missing before assembling.
- 7. To avoid injury or damage to the fitting, please ensure that power leads and screws are secure before connecting the power.
- 8. Please keep instructions for future reference.
- 9. Please refer to IP (Ingress Protection) rating of this luminaire when deciding the location of installation.

Surface Mount Installation



- a. Type Y: If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or by a service agent or licenced electrician in order to avoid hazard.
- र्भि Non-user replacable light source.
- c. The lens cover of the luminaire is secured by glue, unremovable.

Product Reference

COMPLETE

Product Code	AST10W-115	AST15W-145	AST20W-170	AST25W-190	AST30W-235
	AST10W-115-BK	AST15W-145-BK	AST20W-170-BK	AST25W-190-BK	AST30W-235-BK
Product Code (Accessories)	/	/	/	AST25W-SM-WH AST25W-SM-BK	AST30W-SM-WH AST30W-SM-BK







^{*}Please ensure that the Driver is not covered by insulation or other building materials.