## HANECO LED DOWNLIGHT INSTALLATION GUIDE

## **METEOR**

Thanks for choosing our second generation METEOR LED surface mount downlight products.


We strongly recommend that you read this manual carefully before installation.

## **Installation Instructions**






- Switch OFF main power
   Drill holes in mounting surface
- and install plug anchors.




3. Install mounting bracket to surface.







4. Select colour temperature using slide switch.



5. Wire the fitting as diagram above



Secure fitting on mounting bracket using screws supplied.



1. Switch ON main power

## **N** WARNING

- The luminaire must be installed by professional electrician.
- Switch power off when wiring the luminaire.
- Ensure input voltage conforms to the voltage range of product.
- Ensure wires are securely connected.
- Before switching on, ensure that all the wiring is correct.
- The warranty is void if product is not installed according to the instructions.

M13W90R-WH -TRI
Product Code: M13W90R-BK-TRI

M20W130R-WH-TRI M20W130R-BK-TRI M35W160R-WH-TRI M35W160R-BK-TRI

