


# Lens replacement instructions


PARX75W | PARX150W | PARX200W | PARX300W

## Step:


The number of accessories varies depending on the power, please pay attention to differentiation.




1.Remove the lens and sealing ring by using tools to remove the screws and store them properly




2.Install the sealing ring onto the new lens;



4.Cover the new lens onto the PCB and secure it with screws;



3.Install the silicone pad into the hole position of the PCB;



5.Replacement completed;