
HANECO LIGHTING LED INSTALLATION GUIDE


LED YOUR FUTURE

Haneco lighting LED Downlight allows the minimum clearance around heat sink, Including thermal insulation and building structural members to be at a minimum of 25mm. This clearance is based on maximum ambient temperature of 70°C, The electronic LED driver must be located at least 25mm away from the heat sink in a well ventilated area that is not directly.

*Installation Instructions:

- 1. Take LED fitting out from box
- 2. Cut hole as per instruction below
- 3. Put the plug into the socket
- 4. Insert LED Downlight into the pre-cutted hole while gently releasing mounting springs.





PRODUCT CODE: RETRO7W



For more information 1300 001 LED www.haneco.com.au



