


# Lens replacement instructions


Product Code: SKYLUX120W-G5  
SKYLUX200W-G5

## Disassemble lens



1. Remove sealing cover by turning counterclockwise
2. Remove the lens screws with an electric screwdriver
3. Put the waterproof cover, lens outer ring screws and lens waterproof ring in place to use when replacing a new lens

## Replace with a new lens



1. Assemble the removed lens seal into the new lens, paying attention to the assembly direction of the seal, as shown in the figure
2. The convex point of the lens is aligned with the notch of the radiator
3. Replace the middle two screws with new screws with sealing rings
4. Put in a new waterproof cover seal
5. Reinstall the previously removed waterproof cover from the new