

# SKYLUX-FG<sup>PRO</sup>


## FoodGrade Highbay Lens & Reflector

### Optional Accessories

## INSTALLATION GUIDE



**LENS**



**REFLECTOR**

#### LENS

PRODUCT CODE	DESCRIPTION
SLFGPSL60300	SKYLUX FOODGRADE PRO HIGHBAY LENS: 60° (60/80/100W FIXTURE)
SLFGPLL60345	SKYLUX FOODGRADE PRO HIGHBAY LENS: 60° (120/150/160W FIXTURE)
SLFGPSL90300	SKYLUX FOODGRADE PRO HIGHBAY LENS: 90° (60/80/100W FIXTURE)
SLFGPLL90345	SKYLUX FOODGRADE PRO HIGHBAY LENS: 90° (120/150/160W FIXTURE)

#### REFLECTOR

PRODUCT CODE	DESCRIPTION
SLFGPPCRL	SKYLUX FOODGRADE PRO HIGHBAY PC REFLECTOR - UNIVERSAL


- Please read instruction carefully before assembling and installation
- Please keep instruction as reference in the future

## ● WARNING


1. Ensure that any installation and maintenance be performed by a qualified electrician and the luminaire is wired in accordance with the local wiring and relevant Australia standards.
2. Ensure that the power supply is off before starting installation and maintenance. Do not switch on until the installation or maintenance is completed.
3. Make sure the luminaires are grounded.

## ● PC REFLECTOR INSTALLATION


1. Lock the 4 studs on to the lamp, if you have a 100W model, please ignore this step.




2. Install the PC reflector.



3. Fasten the 4 screws on to the studs.




4. The install of the PC reflector is completed.




## ● INTERCHANGEABLE LENSES INSTALLATION


1. Unfasten all the screws that attaching the lens to the fixture.




2. Remove the existing lens




3. Remove the sealing ring from the original lens and install it on the new lens.



5. Attach the new lens to the lamp.



6. Fasten the new lens with the screws that were removed at STEP 1.



**SERVICE CONTACT:**

**HANECO**

Haneco Lighting Australia Pty Ltd  
262 Marion Road, Netley, South Australia 5037  
Haneco.com.au  
1300 001 533