

HANECO LED BATTEN INSTALLATION GUIDE

VISTA SERIES






Thanks for choosing our VISTA batten series products.
We strongly recommend that you read this manual carefully before installation.

WARNING

The luminaire must be installed by a professional electrician. Switch power off when wiring the luminaire. Ensure input voltage conforms to the voltage range of product. Ensure wires are securely connected. Before switching on, ensure that all the wiring is correct. The warranty is void if product is not installed according to the instructions.

MODEL	POWER	Voltage	Frequency	Dimensions	Fix Hole Centre
VISTA12-SS	18/36W	AC 220-240v	50/60Hz	1221 x 84 x 70mm	912mm

Installation Instructions



NOTE: For Intellisensor models, see attached leaflet for setup guide.

